

1D Barcode Scanner

Quick Start Guide

System Setting



Restore factory value (000B0)



Show version number (000A0)



Turn on sound (014201)



Turn off sound (014200)

Reading Mode



Trigger Mode*



Continuous Mode

Suffix Setting



Add enter (0212@\r)



Add enter and newline (0213@\r\n)



addTAB(0212@\t)



No terminator (0210@)

System Setting



Restore wireless default parameters
(%%Restore)



One-click pairing (%%EZPair)



Display battery level (%%Batt)



Power off(%%POWEROFF)

Dormancy Time



Sleep time SET (%%ALLTIMSET)



30 sec(%%ALLTIM01)



60 sec(%%ALLTIM02)




5 min(%%ALLTIM04)



No dormancy (%%ALL*TIDIS)

Mode setting



Normal mode (%%ALLPT-SET)



Inventory mode (%%ALLMEM-SET)



No loss mode (%%ALLAEM-SET)

Data management



Data upload (%%ALLMEM-SC)



Total data (%%ALLMEM-ZS)



Clear data (%%ALLMEM-QC)

Test code



123456789



1 234567 891231

Note: only the wireless version can scan the code to set the Inventory mode, but not the wired version!