

1D Barcode Scanner

User Manual

System Setting



0B

Factory Defaults



0A

Show Version number



0B142

Open sound



014200

Close Sound

Interface Setting




000602

Usb/Default



000600

Ps/2 /Keyboard mode



000601

RS232/Serial port mode



000603

VCOM/Virtual serial port

Triggering mode Setting



013300

Default scan mode



013304

Automatic continuous scanning



013305

Automatic flicker



013302

Key delay

Language Setting



0005000

American (default)



0005009

French



0005010

German



0005002

Brazil

Suffix Setting



0212@r

ADD-ENTER



0212@r\n

ADD-ENTER-TAB



0211@[ETX]

ADD-ETX



0210@

Cancel the suffix