

# 一维有线扫码枪

## 用户手册

### 系统设置



0B

恢复出厂设置



0A

显示版本号



0B142

打开声音



014200

关闭声音

### 接口设置



000602

USB/默认



000600

Ps/2 /键盘模式



000601

RS232/串口模式



000603

VCOM/虚拟串口模式

## 扫描模式设置



013300

默认扫描模式



013304

自动连续扫描



013305

自动闪烁



013302

按键延迟

## 语言设置



0005000

美国英语(默认)



0005009

法语



0005010

德语



0005002

巴西

## 后缀设置



0212@r

添加回车



0212@r\n

添加回车和换行



0211@[ETX]

添加 ETX



0210@

取消后缀